



Parts List for JB600 Type 0

Item Number	Part Number	Description	Qty Required
1	JB600-10	REAR PIVOT PIN- JB60	2
2	85018	RING	4
3	JB600-1	MOUNT BRKT ASSY- JB6	1
4	JB600-2	COVER ASSY- JB600	1
5	JB600-7	LINK ASSEMBLY	1
6	JB600-11	CYLINDER ASSY	1
7	JB600-4	PUSHER BLOCK	1
8	JB600-8	CAM ROLLER	3
9	JB600-13	LINK PIVOT PIN	1
10	JB600-17	SCREW- SET- BR TIP	1
11	JB600-19	SCREW- CYL RET.- JB6	2
12	JB600-18	NUT- 10/32 NYLOCK	2
13	JB600-5	BUSHING	2
14	JB600-12	ROLLER PIN	1
15	JB600-16	COVER SCREW- JB600	3
16	JB600-14	P6C-8 FOR AIR DRIVE	1
17	JB600-20	TRIGGER LEVER SPRING	1
18	JB600-21	TRIGGER LEVEL RIVET	1
19	100406	DRIVE BEARING- P6	2
20	100399	PUSHER	1
21	P627-S	BOSTITCH SPRING	1
22	100400	RETAINER- P6	1
23	100402	DRIVER- 5019	1
24	100404	CLINCHER ARM SPRING	1
25	100407	MAGAZINE COVER- P6	1
26	100409	LOADING GUIDE- P6	1
27	100405	MAGAZINE SPRING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for JB600 Type 0

Item Number	Part Number	Description	Qty Required
28	100392	DRIVER ARM-P6-BLACK	1
29	100393	CLINCHER ARM	1
30	100538	CORE - 5019	1
31	100537	MAGAZINE - 5019	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.