


MODEL XS3650

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



SPOTNAILS MODEL XS3650

| Ref No. | Part No. | Description |
|---------|----------|-----------------------------------|
| 01 | P-24370 | Screw |
| 02 | P-96118 | Bushing |
| 03 | P-70041 | Exhaust Deflector |
| 04 | P-64377 | O-Ring |
| 05 | P-24300 | Cap Screw |
| 06 | P-32211 | Flat Washer |
| 07 | P-60172 | Cap |
| 08 | P-15187 | Exhaust Seal |
| ◆ | 09 | P-64378 O-Ring |
| ◆ | 10 | P-18327 Poppet Spring |
| ◆ | 11 | P-64028 Poppet O-Ring |
| ◆ | 12 | P-63037 Poppet |
| ◆ | 13 | P-64379 Piston Stop O-Ring |
| ◆ | 14 | P-64380 Cylinder Seal O-Ring |
| ◆ | 15 | P-03079 Guide Spacer |
| ◆ | 16 | P-62070 Gasket |
| ◆ | 17 | P-64228 Piston O-Ring |
| ◆ | 18 | AS-06044 Piston & Driver Assembly |
| ◆ | 19 | P-64330 Cylinder O-Ring |
| ◆ | 20 | P-05096 Cylinder |
| ◆ | 21 | P-64419 O-Ring |
| ◆ | 22 | P-15197 Bumper |
| ◆ | 23 | P-01263 Body |
| ◆ | 24 | P-64312 O-Ring |
| ◆ | 25 | P-60156 End Cap |
| ◆ | 26 | P-07262 Pin |
| ◆ | 27 | P-15203 Return Seal |
| ◆ | 28 | P-24358 Screw |
| ◆ | 29 | P-10285 Stationary Front Plate |
| ◆ | 30 | P-07357 Step Pin |
| ◆ | 31 | P-10291 Removable Front Plate |
| ◆ | 32 | P-18333 Latch Spring |
| ◆ | 33 | P-08475 Wear Plate |
| ◆ | 34 | P-04062 Quick Clear Latch |
| ◆ | 35 | P-53165 Safety Guide |

| Ref No. | Part No. | Description |
|---------|----------|--|
| 36 | P-18328 | Spring |
| 37 | AS-53045 | Safety Assembly |
| 38 | P-64332 | Valve Housing O-Ring |
| 39 | P-22144 | Trigger Valve Cap |
| ◆ | 40 | P-64333 O-Ring |
| ◆ | 41 | P-64334 O-Ring |
| ◆ | 42 | P-64335 O-Ring |
| ◆ | 43 | P-22145 Pilot Valve |
| ◆ | 44 | P-64336 O-Ring |
| ◆ | 45 | P-18227 Spring |
| ◆ | 46 | P-64383 Plunger O-Rings |
| ◆ | 47 | AS-22037 Plunger Assembly |
| ◆ | 49 | P-64328 O-Ring |
| ◆ | 50 | P-64240 O-Ring |
| ◆ | 51 | P-07327 Trigger Pin |
| ◆ | 52 | AS-21008 Trigger Assembly |
| ◆ | 53 | P-26126 Nut |
| ◆ | 54 | P-24430 Screw |
| ◆ | 55 | P-24432 Screw |
| ◆ | 56 | P-12417 Magazine Cover |
| ◆ | 57 | P-07335 Negator Spring Pin |
| ◆ | 58 | P-18334 Negator Spring |
| ◆ | 59 | P-13073 Bracket |
| ◆ | 60 | P-24301 Screw |
| ◆ | 61 | P-26159 Nut Plate |
| ◆ | 62 | P-24433 Screw |
| ◆ | 63 | P-24434 Screw |
| ◆ | 64 | P-09188 Pusher |
| ◆ | 65 | P-12426 Magazine |
| ◆ | 66 | P-07339 Pin |
| ◆ | 67 | P-53167 Lathing Safety (Optional) |
| ◆ | 68 | P-06223 Driver Blade |
| ◆ | 69 | P-32170 Washer |
| ◆ | 70 | P-97454 Filter (Optional) |
| ◆ | 71 | AS-21026 Restrictive Trigger Assembly (Optional) |

◆ Parts Included In AS-97293 O-Ring And Seal Kit